



Andoer HDV 107 Battery Replacement

Remove the battery from the camera.

Written By: Isaac Saron



INTRODUCTION

This is a simple guide to remove the battery. This might be needed if your battery is dead and want to replace it.

Step 1 — Battery



- At the bottom of the camera you will see the battery compartment cover as seen in the picture.
- To open this compartment, apply pressure in the direction of the arrow and remove.

Step 2



- You will see the battery being held in place by a clear plastic kickstand.
- Use your finger to move the kickstand away from the battery.

Step 3



- With your other hand press down on the battery slightly and remove the battery.
- ⓘ If the battery does not come out right away try to line the battery up with the sides to give it a clear path out of the compartment.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-02 03:00:29 PM.